



CAN-2 Radio Receiver

Instruction Manual



MAGNETEK

March 2019

Part Number: 198-80100-0001 R08

©Copyright 2019 Magnetek Material Handling

Page Intentionally Left Blank

Table of Contents

1	Introduction	6
1.1	Product Manual Safety Information	6
1.2	Warnings and Cautions	7
2	Critical Installation Considerations	8
2.1	General	8
2.2	Persons Authorized to Operate Radio-Controlled Equipment	8
2.3	Safety Information and Recommended Training for Radio-Controlled Equipment Operators	9
2.4	Pre-Operation Test	10
3	CAN-2 Receiver Installation	11
3.1	Pre-Installation	11
3.2	Mechanical Drawings	12
3.3	Installation	13
3.4	Removal of CAN-2 from Housing	14
3.5	CAN Terminating Resistor Setting	14
3.6	Reinstallation of CAN-2 to Housing	15
3.7	Pinout Diagram and Definitions	15
3.8	Connector Component Information	17
4	Operation	18
4.1	Initialization	18
4.2	Normal Operation	18
4.3	LED Status Indication	18
4.4	Infrared Communication	20
4.5	RS-485 Daughter Board (Optional)	20
5	Programming with RCP	22
5.1	Access Codes	22
5.2	Changing Transmitter Access Codes	22
5.3	Connecting the CAN-2 to a Computer	23
5.4	Programming with RCP	24
6	Channel and Frequency Designations	32
6.1	400 MHz Part 15	32
6.2	419 MHz Extended Channel Set	33
6.3	900 MHz Part 15	35
6.4	2.4 GHz: FHSS	36
6.5	FCC Statements	36
7	Troubleshooting	37
7.1	Troubleshooting Table	37
7.2	Assembly and Replacement Parts	38
8	EU Declaration of Conformity	39

Page Intentionally Left Blank

SERVICE CONTACT INFORMATION

Your New Radio Remote Control System

Thank you for your purchase of Magnetek's CAN-2 Radio Receiver. Magnetek has set a whole new standard in wireless control performance, dependability, and value with this unique line of radio controllers.

If your product ever needs modification or service, please contact one of our representatives at the following locations:

U.S. Service Information

For questions regarding service or technical information, contact:

1-866-MAG-SERV

(1-866-624-7378)

International Service

262-783-3500

World Headquarters:

Magnetek, Inc.

N49 W13650 Campbell Drive

Menomonee Falls, WI 53051

Telephone: 800-288-8178

Website: www.magnetek.com

E-mail: mhcustomerservice@magnetek.com

Fax Numbers:

Main: 800-298-3503

Sales: 262-783-3510

Service: 262-783-3508

Canada Service Information:

161 Orenda Road

Unit 1

Brampton, Ontario

L6W 1W3 Canada

Phone: 800-792-7253

Fax: 905-828-5707

416-424-7617 (24/7 Service pager)

EU Market Contact:

Brian Preston

Magnetek (UK) Ltd.

Unit 3 Bedford Business Centre

Mile Road

Bedford, MK42 9TW UK

Phone: +44-1234-349191

© 2019 MAGNETEK

All rights reserved. This notice applies to all copyrighted materials included with this product, including, but not limited to, this manual and software embodied within the product. This manual is intended for the sole use of the person(s) to whom it was provided, and any unauthorized distribution of the manual or dispersal of its contents is strictly forbidden. This manual may not be reproduced in whole or in part by any means whatsoever without the expressed written permission of MAGNETEK.

1 Introduction

Thank you for your purchase of Magnetek's CAN-2 Radio Wireless Receiver.

These instructions are to be used as a reference for personnel operating the Magnetek CAN-2 Radio Wireless Receiver and the equipment that this CAN-2 Radio Wireless Receiver is attached to.

The user of these instructions should have basic knowledge in the handling of electronic equipment.

1.1 Product Manual Safety Information

Magnetek, Inc. (Magnetek) offers a broad range of radio remote control products, control products, adjustable frequency drives, and industrial braking systems for overhead material handling applications. This manual has been prepared by Magnetek to provide information and recommendations for the installation, use, operation and service of Magnetek's material handling products and systems (Magnetek Products). Anyone who uses, operates, maintains, services, installs or owns Magnetek Products should know, understand and follow the instructions and safety recommendations in this manual for Magnetek Products.

The recommendations in this manual do not take precedence over any of the following requirements relating to cranes, hoists and lifting devices:

- Instructions, manuals, and safety warnings of the manufacturers of the equipment where the radio system is used,
- Plant safety rules and procedures of the employers and the owners of facilities where the Magnetek Products are being used,
- Regulations issued by the Occupational Health and Safety Administration (OSHA),
- Applicable local, state or federal codes, ordinances, standards and requirements, or
- Safety standards and practices for the overhead material handling industry.

This manual does not include or address the specific instructions and safety warnings of these manufacturers or any of the other requirements listed above. It is the responsibility of the owners, users and operators of the Magnetek Products to know, understand and follow all of these requirements. It is the responsibility of the owner of the Magnetek Products to make its employees aware of all of the above listed requirements and to make certain that all operators are properly trained. **No one should use Magnetek Products prior to becoming familiar with and being trained in these requirements.**

WARRANTY INFORMATION

FOR INFORMATION ON MAGNETEK'S PRODUCT WARRANTIES BY PRODUCT TYPE, PLEASE VISIT WWW.MAGNETEKMObILEHYDRAULIC.COM.

1.2 Warnings and Cautions

Throughout this document WARNING and CAUTION statements have been deliberately placed to highlight items critical to the protection of personnel and equipment.



WARNING

WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury. It may also be used to alert against unsafe practices.

NOTE: A NOTE statement is used to notify people of installation, operation, programming, or maintenance information that is important, but not hazard-related.

WARNINGS and CAUTIONS SHOULD NEVER BE DISREGARDED.

The safety rules in this section are not intended to replace any rules or regulations of any applicable local, state, or federal governing organizations. Always follow your local lockout and tagout procedure when maintaining any radio equipment. The following information is intended to be used in conjunction with other rules or regulations already in existence. It is important to read all of the safety information contained in this section before installing or operating the Radio Control System.

2 Critical Installation Considerations



WARNING

Prior to installation and operation of this equipment, read and develop an understanding of the contents of this manual and the operation manual of the equipment or device to which this equipment will be interfaced. Failure to follow this warning could result in serious injury or death and damage to equipment.

All equipment must have a mainline contactor installed and all tracked cranes, hoists, lifting devices and similar equipment must have a brake installed. Failure to follow this warning could result in serious injury or death and damage to equipment.

An audible and/or visual warning means must be provided on all remote-controlled equipment as required by code, regulation, or industry standard. These audible and/or visual warning devices must meet all governmental requirements. Failure to follow this warning could result in serious injury or death and damage to equipment.

Follow your local lockout/tagout procedure before maintaining any remote-controlled equipment. Always remove all electrical power from the crane, hoist, lifting device or similar equipment before attempting any installation procedures. De-energize and tagout all sources of electrical power before touch-testing any equipment. Failure to follow this warning could result in serious injury or death and damage to equipment.

The direct outputs of this product are not designed to interface directly to two state safety critical maintained functions, i.e., magnets, vacuum lifts, pumps, emergency equipment, etc. A mechanically locking intermediate relay system with separate power considerations must be provided. Failure to follow this warning could result in serious injury or death or damage to equipment.

2.1 General

Radio-controlled material handling equipment operates in several directions. Cranes, hoists, lifting devices and other material handling equipment can be large, and can operate at high speeds. The equipment is often operated in areas where people are working in close proximity to the material handling equipment. **The operator must exercise extreme caution at all times.** Workers must constantly be alert to avoid accidents. The following recommendations have been included to indicate how careful and thoughtful actions may prevent injuries, prevent damage to equipment, or even save a life.

2.2 Persons Authorized to Operate Radio-Controlled Equipment

Only properly trained persons designated by management should be permitted to operate radio-controlled equipment.

Radio-controlled cranes, hoists, lifting devices and other material handling equipment should not be operated by any person who cannot read or understand signs, notices and operating instructions that pertain to the equipment.

Radio-controlled equipment should not be operated by any person with insufficient eyesight or hearing or by any person who may be suffering from a disorder or illness that may cause them to lose control of the equipment, is taking any medication that may cause loss of equipment control, or is under the influence of alcohol or drugs.

2.3 Safety Information and Recommended Training for Radio-Controlled Equipment Operators

Anyone being trained to operate radio-controlled equipment should possess as a minimum the following knowledge and skills before using the radio-controlled equipment.

The operator should:

- have knowledge of hazards pertaining to equipment operation
- have knowledge of safety rules for radio-controlled equipment
- have the ability to judge distance of moving objects
- know how to properly test prior to operation
- be trained in the safe operation of the radio receiver as it pertains to the crane, hoist, lifting device or other material handling equipment being operated
- have knowledge of the use of equipment warning lights and alarms
- have knowledge of the proper storage space for a radio control receiver when not in use
- be trained in transferring a radio control receiver to another person
- be trained how and when to report unsafe or unusual operating conditions
- test the receiver emergency stop and all warning devices prior to operation; testing should be done on each shift, without a load
- be thoroughly trained and knowledgeable in proper and safe operation of the crane, hoist, lifting device, or other material handling equipment that utilizes the radio control
- know how to keep the operator and other people clear of lifted loads and to avoid “pinch” points
- continuously watch and monitor status of lifted loads
- know and follow cable and hook inspection procedures
- know and follow the local lockout and tagout procedures when servicing radio-controlled equipment
- know and follow all applicable operating and maintenance manuals, safety procedures, regulatory requirements, and industry standards and codes

The operator shall not:

- lift or move more than the rated load
- operate the material handling equipment if the direction of travel or function engaged does not agree with what is indicated on the controller
- use the crane, hoist or lifting device to lift, support or transport people
- lift or carry any loads over people
- operate the crane, hoist or lifting device unless all persons, including the operator, are and remain clear of the supported load and any potential pinch points
- operate a crane, hoist or lifting device when the device is not centered over the load
- operate a crane, hoist or lifting device if the chain or wire rope is not seated properly in the sprockets, drum or sheave
- operate any damaged or malfunctioning crane, hoist, lifting device or other material handling equipment
- change any settings or controls without authorization and proper training
- remove or obscure any warning or safety labels or tags
- leave any load unattended while lifted
- leave power on the radio-controlled equipment when the equipment is not in operation
- operate any material handling equipment using a damaged controller because the unit may be unsafe
- operate manual motions with other than manual power
- operate radio-controlled equipment when low battery indicator is on



WARNING

The operator should not attempt to repair any radio controller. If any product performance or safety concerns are observed, the equipment should immediately be taken out of service and be reported to the supervisor. Damaged and inoperable radio controller equipment should be returned to Magnetek for evaluation and repair. Failure to follow this warning could result in serious injury or death and damage to equipment.



WARNING

To avoid electrostatic discharge that could damage the product, the operator should avoid contact with the receiver antenna port.

2.4 Pre-Operation Test

At the start of each work shift, or when a new operator takes control of the crane, operators should do, as a minimum, the following steps before making lifts with any crane or hoist:

Test all warning devices.

Test all direction and speed controls.

Test the receiver emergency stop.

3 CAN-2 Receiver Installation



WARNING

Before operating the receiver, familiarize yourself with all safety information in this manual, appropriate manual supplements and any other local, state, or federal rules or regulations already in existence. Failure to follow this warning could result in serious injury or death and damage to equipment.

3.1 Pre-Installation

1. The transmitter and receiver access code and channel must match before the system will communicate.
2. Be aware of other radio channels in the surrounding area. Set your system to a unique channel.
3. Make sure that your equipment is working properly in manual mode prior to system installation.
4. Make sure the power to the receiver is the correct DC voltage.
5. Ensure adequate suppression is provided at the power input.
6. Disconnect equipment power prior to system installation.

3.2 Mechanical Drawings




Fig. 1: Remote Antenna (marked in red)




Fig. 2: CAN-2 with External Antenna (red)




Fig. 3: CAN-2 with Internal Antenna (red)




Fig. 4: CAN-2 Bottom View




Fig. 5: CAN-2 Side View

3.3 Installation

1. Determine the location of your antenna from **Fig. 1** through **Fig. 3** (the antenna is designated with the red arrow). **Be sure to mount the receiver antenna in direct line-of-sight of the operator and free from all obstructions.**
2. Do not mount the receiver near high levels of electric noise, such as an unshielded variable-frequency drive, as it may cause minor interference. When mounting the CAN-2 near unshielded variable-frequency drive, **Magnetek typically recommends that the CAN-2 and all antenna cable routing be mounted a minimum of 24 inches from all unshielded variable-frequency drives and cables.**
3. Allow adequate room for mounting the receiver. Make sure to allow a minimum of 5" between the connector and the nearest surface to allow for cable harness connections.
4. For best reception and to help protect connectors from moisture and water damage, mount the receiver in an upright position.

5. If obstructions cannot be cleared, or the unit must be mounted inside a metal enclosure, the remote antenna should be used (*see Fig. 1*).
6. Do not enclose the antenna in steel. For best reception, keep all metal objects away from the antenna. **Consult the factory for more information regarding your application.**
7. The power supply to the CAN-2 system must have a master disconnect.

NOTE: Magnetek strongly recommends the use of circuit disconnects for all CAN-2 receivers. Consult factory for more information.

3.4 Removal of CAN-2 from Housing

It might be necessary to access the internal circuit board on the receiver to adjust the CAN terminating resistor jumper.

To remove the CAN-2 receiver from the housing, first remove power from the CAN-2 receiver by turning off the master disconnect. Remove the connectors from the bottom of the receiver by squeezing in the release tabs on both sides of the connector. Remove the bottom connector plate with the internal circuit board by inserting a flat screwdriver into the top slots for the two side release tabs and giving a gentle twist.




Fig. 6: CAN-2 Housing Removal Procedure

After releasing both sides, one at a time, gently pull the circuit board from the housing. This may require gently rocking it side to side as it is being removed.

3.5 CAN Terminating Resistor Setting

For CAN signaling to work correctly, the first and last devices on the CAN bus must have terminating resistors of 120 ohms. The CAN-2 has a built-in terminating resistor that can be enabled or disabled by a built-in jumper.

After removing the CAN-2 receiver from the housing, locate the terminating resistor jumper (P2) on the PCB near the main connector in the lower right, as seen in *Fig. 7*.




Fig. 7: CAN-2 Terminating Resistor Location




Fig. 8: CAN-2 Terminating Resistor Setting

When the jumper is matched to the “TERM” position the terminating resistor is enabled. When the jumper is in any other position, the terminating resistor is disabled.

3.6 Reinstallation of CAN-2 to Housing

To reinstall, slide the board and connector plate into the housing and press firmly to fully seat the bottom connector plate onto the housing.

3.7 Pinout Diagram and Definitions




Fig. 9: Pinout Diagram

Table 1: Connector Connections

PIN	FUNCTION	DESCRIPTION
1	CANL	CANL
2	CANH	CANH
3	CAN REF	Common
4	CANL	CANL
5	CANH	CANH
6	-VBATT	Common
7	+VBATT	+12 - 24VDC Power
8	USB D+	USB Data
9	USB D-	USB Data
10	USB REF	USB Common
11	OUTPUT2	Output/ESTOP 2
12	OUTPUT1	Output/ESTOP 1

+VBATT (Pin 7)

The CAN-2 is designed to work in any 12 - 24VDC nominal (9 - 36VDC max.) powered equipment. The +VBATT pins should be connected to the positive terminal of the machine power supply through an approved emergency stop device.

-VBATT (Pin 6)

The -VBATT connections must be made directly to the negative supply and not to the chassis ground.

NOTE: Added suppression can be placed in between -VBATT (pin 6) and +VBATT (pin 7) to the level needed for the system in use. Use Magnetek part number 07-205-005E (33V 5kW TVS) for typical suppression needs.

Machine Stop Outputs (Pins 11 and 12)

In order to ensure maximum safety of the equipment controlled by the CAN-2, a Machine Stop output is recommended. Pins 11 and 12 can be set as Machine Stop outputs for redundancy, or pin 12 can be set as a single Machine Stop output (**see Section 5.4 on page 24** on how to configure the outputs). Pins 11 and 12 are high side switch outputs that can supply a current of up to 6 amps per output. When configured as Machine Stop outputs, these are normally closed and will go to an open state in the event of an unsafe condition. These events include loss of communications from the transmitter or Machine Stop activation on the transmitter. Turning off the transmitter will also deactivate these outputs. Refer to project-specific drawings for any special configuration of these outputs.

NOTE: Use of clamping diodes is recommended for optimal performance and longevity of the Machine Stop output circuits. The same suppression diode used between -VBATT (pin 6) and +VBATT (pin 7) (Magnetek part number 14-105-0021E) is used with the cathode on the positive lead and the anode to the -VBATT return line for the valve to be protected (**see Fig. 10**).




Fig. 10: CAN-2 Machine Stop Wiring

Additionally, make sure that a Machine Stop is provided elsewhere on the equipment in which the CAN-2 is installed in order to comply with all applicable Machinery Directives.

CAN (Pins 1, 2, 4, and 5)

There is only one CAN bus on the CAN-2. There are two sets of pins to support proper daisy-chained connections to a CAN network.

CAN Reference (Pin 3)

On isolated CAN-2 devices, pin 3 should be connected to the common pin of the device using the isolated CAN bus. On non-isolated CAN-2 units, this pin can be connected to the system common.

3.8 Connector Component Information

Table 2: Connector Part Numbers

DEUTSCH Connector Information	DEUTSCH Part #	Magnetek Part #
Connector Housing	DTM06-12SA	01-525-0029E
Wedge Lock	WM-12S	01-525-0030E
Crimp (16-22 AWG)	1062-20-0122-PS	01-550-0029E
Connector Boot	DTM12S-BT (Gray)	20-990-0092E
Connector Kit (all components above)	N/A	25-04-030-163E
CAN RX 6' Harness Assembly	N/A	25-04-030-173E

4 Operation

During normal operation the CAN-2 receiver will receive commands from the transmitter and convert them to output or CAN signals. During these operations, the operator can verify that the receiver is online and functioning by interpreting the status LED lights on the front of the CAN-2 receiver. If there are errors during operation, the LED lights can help troubleshoot the problem.

4.1 Initialization

During startup of the CAN-2 module, the signal strength/error code LED will illuminate to provide initialization status.

Slow Blink Green = Initialization OK, no errors present

Blinking Red = Startup initialization error

After initialization is complete, the LED will then illuminate the signal strength and error code status as part of the normal operation.

4.2 Normal Operation

During normal operation of the receiver, the receiver will receive commands from the transmitter and convert them into outputs or CAN messages. During operation, the receiver will communicate its status via LEDs.



WARNING

Do not assume the power is off in the receiver because the transmitter is turned off. Failure to follow this warning could result in serious injury or death and damage to equipment.

4.3 LED Status Indication

The CAN-2 has three LEDs for indicating the CAN-2 status at a glance during normal operation:

- The center LED labeled STATUS indicates the CAN-2's signal strength/error codes.
- The top LED (RF) indicates receiving of RF messages.
- The bottom LED (COM) indicates received CAN data.

4.3.1 RF Messages LED (Labeled RF on CAN-2 Faceplate)

- Green Slow Blinks = Transmitter is offline (watchdog indicator)
- Green Fast Blinks = Each blink is a valid RF message
- Red Solid = Error occurred; refer to Error Code LED's blink code

4.3.2 Signal Strength/Error Code LED (Labeled STATUS on CAN-2 Faceplate)

- Solid Green = Good RF signal strength to transmitter
- Solid Yellow = Average RF signal strength to transmitter
- Solid Red = Low RF signal strength to transmitter
- Blinking Red = Error (code is picked up from number of blinks)
 - Red 2 Blinks - Commanded Power Down
 - Red 3 Blinks - RF Data Timeout
 - Red 4 Blinks - CAN bus Timeout
 - Red 5 Blinks - Initialization / Hardware Error
 - Red 6 Blinks - Machine Stop Power Down
 - Red 7 Blinks - Invalid RF Firmware

See Section 7 on page 37 for the troubleshooting table to interpret error codes.

NOTE: SIGNAL STRENGTH/ERROR CODE LED only illuminates green when the receiver is online with the transmitter. The SIGNAL STRENGTH/ERROR CODE LED will not illuminate green after the transmitter goes offline from the receiver. This can occur when the transmitter powers down from inactivity or goes out of range. The START toggle on the transmitter must be toggled to bring the transmitter back online with the receiver.

4.3.3 Communication LED (Labeled COM on CAN-2 Faceplate)

The COM LED will function differently depending on the CAN protocol.

- J1939 and generic CAN
 - During normal operation, if there is CAN data currently being received on the bus, this LED will blink blue as an indication that a CAN message has been received.
- CANOpen Communication States
 - Initialization/Preoperational - Slow Green Blink
 - Operational - Solid Green
 - Stop State - Single Green Blink, repeated
 - Error State - Solid Red

4.4 Infrared Communication

The CAN-2 is equipped with an infrared (IR) port that is used when pairing a transmitter with the CAN-2. Refer to the appropriate transmitter manual for instructions on how to use this feature (if supported by the transmitter).

The IR port is accessible when the board is within the housing. There is no need to remove the board from the housing to utilize the IR pairing feature. **See Fig. 11** for the location of the IR port on the CAN-2.




Fig. 11: CAN-2 Infrared Port Location (red)

4.5 RS-485 Daughter Board (Optional)

When the CAN-2 contains the RS-485 daughter board, a secondary connector is populated on the face plate to the left side of the primary connector opposite the RP-SMA RF connector as seen in **Fig. 12**. The pinout for the connector is shown in Table 3.




Fig. 12: CAN-2 with Daughter Board Connector

Table 3: RS-485 Connector Connections

PIN	FUNCTION	DESCRIPTION
1	ANALOG IN	Analog Input
2	COM	Common
3	RXA	RX- (Noninverting receiver)
4	RXB	RX+ (Inverting receiver)
5	TXZ	TX+ (Inverting driver)
6	TXY	TX- (Noninverting driver)

5 Programming with RCP

Using the RCP software allows for simple configuration of the CAN-2, and allows for settings to be saved for future reference.



WARNING

The use of RCP (Radio Control Programmer) is intended for use by authorized persons only. Changes to any radio data value may lead to unexpected, undesirable, or unsafe operation of equipment and furthermore may lead to equipment damage, personal injury, or even death. All equipment operators and/or personnel should be notified of any radio data value changes that may affect operation.

5.1 Access Codes

The receiver and transmitter must be programmed with the same access code to properly communicate with each other.



WARNING

Two operational transmitters with the same access codes operating at the same time is a definite safety hazard. Do not operate them at the same time. Failure to follow this warning could result in serious injury or death and damage to equipment.

5.2 Changing Transmitter Access Codes

Transmitter Access Code Programming. For detailed instructions on setting parameters, including access codes, see the “Programming” section of the applicable transmitter manual.



WARNING

After changing the access codes on the transmitter, test the unit by turning it on and off near the appropriate receiver. If the receiver does not respond, do not activate a function button! The transmitter may have the wrong access code, which could move other equipment. Re-check the access code in the transmitter and retest. Failure to follow this warning could result in serious injury or death and damage to equipment.



WARNING

The access codes in the receiver are unique and factory preset. Do not change these access codes unless you are replacing an existing receiver and its access code. Changing this code could make it common with another receiver access code, which could move other equipment. No two systems in any location should ever have the same access codes independent of the frequency. Failure to follow this warning could result in serious injury or death and damage to equipment.

5.3 Connecting the CAN-2 to a Computer

The CAN-2 receiver contains circuits that permit communication with a computer system via USB. If the CAN-2 receiver was ordered with the Pre-Wired Cable Kit, the 195-50539 USB cable can be added by simply plugging in the connector. This option provides a USB-mini B plug for connection to a computer system.

If not using the CAN-2 Pre-Wired Cable Kit, the CAN-2 can be wired for USB connection using the pinouts in **Fig. 13**.




Fig. 13: USB Connection Wiring

When plugging in a CAN-2 receiver to a computer system, it is strongly recommended that a USB isolation hub, like Magnetek part 195-50645, is used between the CAN-2 and the computer system.



WARNING

CAN-2 receivers utilizing a different power source from the computer system being connected to it can have a different ground potential from the computer system. Different ground potentials will damage either the computer system or the CAN-2 receiver. An isolated USB hub must be utilized to prevent damage to the CAN-2, the computer system being connected to the CAN-2, or both.

5.4 Programming with RCP

Magnetek RCP software makes the programming of the CAN-2 receiver easier and allows the programmer to store all of the CAN-2 settings in files for later use or reference. Help is provided for each function at the bottom of the RCP screen. The RCP software allows one to select frequency, access code, and communication configuration. Refer to the RCP User Guide (P/N 178-01702-0010) for additional information on the advanced programming available within RCP. Follow the steps below to set up a new project for the CAN-2 in RCP:

Install the RCP Software

Install the RCP software onto your computer. The software is self-installing; simply insert the USB stick into a USB slot on your computer and follow the onscreen prompts. Refer to the installation instruction sheet for help. You will be prompted to enter an activation code. The code can be found within the packaging that accompanied the USB stick. The software can be used 10 times before product activation is required.


Run the RCP Software

After installation of the RCP software, double-click the RCP icon to launch the program.



New Project or Open Project

Select "New Project" if you are creating a new program file, or select "Open Project" if you want to retrieve an existing program file. A list of recent projects will appear under "Open Project." Clicking on one of these will open that project. It is recommended that you create a folder in which to save all programming files.



For New Projects, Select Device Type

After the “New Projects” icon is selected, a menu listing the available device types will open. Select the device type that matches the product you wish to program (selecting a project type will display a picture of the product for verification).

Receive Device Data Checkbox

At the bottom of the “New Project” window, there is a checkbox that allows the system to automatically upload the setting values from the device upon connection.


NOTE: This checkbox is selected by default.

Having the “Receive Device Data” option checked will cause the program to automatically read the data that is currently on the device upon clicking the “Add” button.



WARNING

If the "Receive Device Data" checkbox is unchecked, the RCP program will overwrite all setting values on the device with default values and any settings changed by the operator upon sending the program to the device. All stored value settings within the device will be replaced, including any project-specific values. Magnetek strongly recommends that the "Receive Device Data" checkbox be left checked.



This screen also allows the programmer to create a specific name for the device to help keep track of device settings and changes. It is recommended that a unique name be chosen for each device programmed with RCP.


5.4.1 CAN-2 Configuration Tabs

The CAN-2 receiver has up to three configuration tabs that are used to configure and program the device. The first tab is the Unit Info tab, which permits configuration of general settings as well as the CAN port configuration. The second tab is the Programming tab, which permits custom programming of the device. The third tab is the FDP tab, which is used to program new firmware into the device. For more information on the Programming and FDP tabs, please refer to the RCP User's Guide.

Unit Info Tab

This page allows the user to view the receiver Project ID and serial number. The user can modify the receiver name, access code, RF channel, receiver timeout, and can determine whether to use an internal or external RF antenna. CAN bus properties are able to be set in this page as well.

NOTE: *Changing any of these details will require a reboot of the CAN-2 after the new information has been sent to the device.*



The Unit Info page is divided into three sections. The left section is the Unit Info Properties grid. The middle section, which is the Device Block Diagram, shows the pinout of the unit and each pin's function. Clicking on a pin or function will show any configurable properties in the Pin Properties grid, which is the right section. Each of these sections is described in greater detail on the following pages.

Unit Info Properties

Unit Info	
☐ Communications	
Frequency	433 MHz
Access Code	12345
RF Channel	1
RF Antenna	Internal
Rx Timeout	450ms
☐ General	
Device Name	CAN-2
Project ID	11111
Serial Number	12345
Program Loaded	False
Device Memory Used	0%

Frequency

This field displays the operating frequency band of the receiver. The receiver radio frequency is set by the factory and cannot be modified by the user.

Access Code

The access code acts as the receiver address. The receiver will only listen to transmitters with the same access code. This feature is selectable by the user.

NOTE: *The transmitter must be set with the same access code as the receiver to properly communicate with each other.*



WARNING

The access codes in the receiver are unique and factory preset. Do not change these access codes unless you are replacing an existing receiver and its access code. Changing this code could make it common with another receiver access code, which could move other equipment. No two systems in any location should ever have the same access codes independent of frequency. Failure to follow this warning could result in serious injury or death and damage to equipment.

RF Channel

The RF channel is user-selectable through the pull-down menu. This function is used to prevent interference with other radio devices. **See Section 6 on page 32** for information about the selectable channels for each frequency band.

RF Antenna

This section allows the user to select between using the internal antenna that is built into the receiver and using the external antenna attachment (if available).

NOTE: Selecting the external antenna when one isn't available will result in reduced RF performance.

Rx Timeout

The Rx Timeout is the amount of time (450 ms to 3000 ms) the unit will keep the Machine Stop outputs closed after the receiver has stopped receiving data from the transmitter.

Device Name

The device name field allows the user to create a custom name for the unit. The name can be up to 16 ASCII characters long.

Project ID

This section displays the Project ID for the unit. The Project ID is set by the factory and cannot be modified by the user.

Serial Number

This section displays the serial number for the unit. The serial number of the unit is set by the factory and cannot be modified by the user.

Pin Properties Grid

By clicking on one of the CAN functions in the Device Block Diagram, the Pin Properties grid will permit the user to change the configuration of the CAN interfaces.

CAN Configuration	
<input checked="" type="checkbox"/> CAN Configuration	
Source Address	0
Baud Rate	50K

Source Address

This is the address that the CAN-2 will use as the source address when transmitting messages on the CAN bus network.

Baud Rate

This pull-down menu allows the user to modify the communication speed of the CAN bus network. The user-selectable options are 50K, 125K, 250K, and 500K.

5.4.2 Programming and Other RCP Software Functions

NOTE: To program or read data from the CAN-2, the receiver must be turned on.

Saving the Programming File

Once programming is complete, click the file tab at the top of the RCP screen to open the file menu. File location and name can be selected from this menu. Old files can be deleted, called up, modified and renamed by this same menu.

Sending a Program to the CAN-2



After every programming of the receiver, test the unit by utilizing the appropriate transmitter. If the receiver does not respond, do not activate a function button! The receiver may have incorrect programming. Re-check the programming in the receiver and retest. After activation of the receiver, functionally test all commands on the transformer by initially jogging the buttons, then with a full movement before returning to service. Failure to follow this warning could result in serious injury or death and damage to equipment.

To send a program file to a CAN-2 Receiver

8. Plug in the USB programming cable or position.
9. Click the "Send" button on the RCP screen. A dialog box will pop up confirming that you want to proceed. Check the box marked "I accept," and then click the button "Continue send to radio." On-screen prompts will confirm that the receiver has been programmed or if there are any issues.
10. Data will need to be sent separately for the Unit Info and CAN Configuration screens.
11. The LEDs on the unit will blink three times when the new data is received and saved.

Receiving (Reading) the CAN-2 Programming

To read a program file from the CAN-2 receiver:

1. Plug in the USB programming cable.
2. Click "Receive" and follow on-screen prompts.
3. RCP will confirm reception and automatically display current programming in the CAN-2 unit.

Reading the RCP Software Version

1. Select "Help."
2. Select "About."
3. RCP Software Version number will be displayed.

Resetting CAN-2 Back to Factory Default Settings

1. Select the "Reset to Defaults" button.
2. A dialog box will pop up confirming that you want to proceed. Click the button "OK" to restore the factory default settings. On-screen prompts will confirm that the receiver has been reset to defaults or if there are any issues.
3. Power-cycle the CAN-2 receiver to implement the factory default values.

6 Channel and Frequency Designations

6.1 400 MHz Part 15

Table 4: 400 MHz Channels

CHANNEL DESIGNATOR	FREQUENCY
01	433.000 MHz
02*	433.050 MHz
03*	433.100 MHz
04*	433.150 MHz
05*	433.200 MHz
06*	433.250 MHz
07*	433.300 MHz
08*	433.350 MHz
09*	433.400 MHz
10*	433.450 MHz
11*	433.500 MHz
12*	433.550 MHz
13*	433.600 MHz
14*	433.650 MHz
15*	433.700 MHz
16*	433.750 MHz
17*	433.800 MHz
18*	433.850 MHz
19*	433.900 MHz
20*	433.950 MHz
21*	434.000 MHz
22*	434.050 MHz
23*	434.100 MHz
24*	434.150 MHz
25*	434.200 MHz
26*	434.250 MHz
27*	434.300 MHz
28*	434.350 MHz
29*	434.400 MHz
30*	434.450 MHz
31*	434.500 MHz
32*	434.550 MHz

NOTE: Frequencies marked with * are approved for use in Australia.

6.2 419 MHz Extended Channel Set

Table 5: 419 MHz Channels

CHANNEL DESIGNATOR	FREQUENCY	CHANNEL DESIGNATOR	FREQUENCY
1*	418.950	44	417.500
2*	418.975	45	417.550
3*	419.000	46	417.600
4*	419.025	47	417.650
5*	419.050	48	417.700
6*	419.075	49	417.750
7*	419.100	50	417.800
8*	419.125	51	417.850
9*	419.150	52	417.900
10*	419.175	53	417.950
11*	419.200	54	418.000
12*	419.250	55	418.050
13*	419.275	56	418.100
14	416.000	57	418.150
15	416.050	58	418.200
16	416.100	59	418.250
17	416.150	60	418.300
18	416.200	61	418.350
19	416.250	62	418.400
20	416.300	63	418.450
21	416.350	64	418.500
22	416.400	65	418.550
23	416.450	66	418.600
24	416.500	67	418.650
25	416.550	68	418.700
26	416.600	69	418.750
27	416.650	70	418.800
28	416.700	71	418.850
29	416.750	72	418.900
30	416.800	73	419.350
31	416.850	74	419.400
32	416.900	75	419.450
33	416.950	76	419.500
34	417.000	77	419.550
35	417.050	78	419.600

CHANNEL DESIGNATOR	FREQUENCY	CHANNEL DESIGNATOR	FREQUENCY
36	417.100	79	419.650
37	417.150	80	419.700
38	417.200	81	419.750
39	417.250	82	419.800
40	417.300	83	419.850
41	417.350	84	419.900
42	417.400	85	419.950
43	417.450	--	--

NOTE: Channels marked with * are approved for use in China.

6.3 900 MHz Part 15

Table 6: 900 MHz Channels

CHANNEL DESIGNATOR	FREQUENCY
1	903.30 MHz
2	906.30 MHz
3	907.80 MHz
4	909.30 MHz
5	912.30 MHz
6	915.30 MHz
7	919.80 MHz
8	921.30 MHz
A	902.30 MHz
B	904.10 MHz
C	904.30 MHz
D	905.10 MHz
E	905.50 MHz
F	905.70 MHz
G	906.60 MHz
H	908.70 MHz
I	908.90 MHz
J	909.10 MHz
K	910.10 MHz
L	910.70 MHz
M	911.00 MHz
N	911.20 MHz
O	912.00 MHz
P	914.20 MHz
Q	914.40 MHz
R	914.60 MHz
S	914.80 MHz
T	915.80 MHz
U	917.40 MHz
V	923.20 MHz
W	927.00 MHz
X	927.30 MHz

6.4 2.4 GHz: FHSS

Channel sets are designated between 1 and 32. The frequency range is between 2402-2478 MHz. The frequency hopping protocol does not use one particular frequency to transmit a message. Messages are transmitted over multiple frequencies in a predefined sequence or channel set. In doing so, this protocol is able to compensate for interference that may be present on a single frequency by sending the message across multiple frequencies.

6.5 FCC Statements

Compliance Statement (Part 15.19)

This device complies with Part 15 of FCC rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Warning (Part 15.21)

Changes or modifications not expressly approved by the party responsible for compliance should void the user's authority to operate the equipment.

This portable transmitter with its antenna complies with FCC's RF exposure limits for general population/uncontrolled exposure.

7 Troubleshooting

7.1 Troubleshooting Table

Problems	Possible Reasons	Suggestions
Receiver will not turn on	Supplied voltage is out of the acceptable range	Ensure the voltage is within 12 - 24 VDC nominal (9 - 36VDC max.).
	Internal fuse has blown	Contact the factory.
Receiver will not respond to the transmitter	Incorrect system RF channel	Make sure the receiver and transmitter unit are both set to the same RF channel.
	Incorrect system access code	Make sure the receiver and transmitter both have the same access code.
	System out of range	Make sure the startup procedure is initiated within 300 feet of the receiver location. If equipped with the Signal Strength Indicator, make sure the level is greater than 0%.
	The antenna on the receiver is missing, damaged, or improperly installed	Inspect the antenna on the receiver for damage and try to place the antenna in a location that is visible when operating the equipment at all times.
	The antenna setting on the receiver is incorrect	Make sure the antenna setting (internal or external) is for the antenna type being used.
	An input on the transmitter is active upon powering up	Make sure all toggles and motions are in their correct positions.
CAN messages are not being received by the receiver	The CAN message being sent is not supported	Use the supported messages OR contact your supplier to inquire about a software update.
	Termination resistor has an incorrect value	Verify that the setting of the terminating resistor is correct for the application.
	Incorrect baud rate	Ensure the correct baud rate is set by all devices on the bus.
CAN messages transmitted by the receiver are not being received	Incorrect source address	Make sure the source address of the receiver is set correctly.
	The termination resistor is set incorrectly	Ensure the termination resistor is appropriately set.
	Incorrect baud rate	Ensure the correct baud rate is set by all devices on the bus.

Problems	Possible Reasons	Suggestions
Outputs not functioning	Faulty wiring	Check all wires for loose or damaged connections.
	Output is shorted or opened	Check all wires and connections for damaged insulation.

7.2 Assembly and Replacement Parts

If your receiver ever needs repair, we always recommend that you have Magnetek perform the repair. If you need to refer to a parts list, refer to your receiver's drawing that was included in the shipment of your receiver. Please contact Magnetek's service department at 1.866.MAG.SERV for information regarding parts and service.

8 EU Declaration of Conformity



MAGNETEK

EU Declaration of Conformity Certificate

For the following equipment:

Product : Enrange Series Radio Remote Control
Manufacturer's Name : Magnetek, Inc.
Manufacturer's Address : N49 W13650 Campbell Drive
Menomonee Falls, WI 53051 USA

The undersigned hereby declares on behalf of Magnetek, that the above-referenced product, to which this declaration relates, is in conformity with the provisions of CE Mark Directive (93/68/EEC), Machinery Safety Directive (MD, 2006/42/EC), Radio Equipment Directive (RED, 2014/53/EU), EMC Directive (2014/30/EU), and the ROHS2 Directive (2011/65/EU).

The standards relevant for the evaluation of the product referenced above conformity to the directive requirements are as follows:

EN 301 489-1 v2.2.0:2017-03	EN 300 328 v2.1.1:2016-11
EN 301 489-17 v2.1.1:2009-05	EN 60204-1:2006
EN 301 489-17 v3.2.0:2017-03	EN 13557:2003+A2:2008
EN ISO 13849-1:2008	EN 60529:1992
EN 300 220-2 v3.1.1:2017-02	EN 60950-1:2006+A11:2009+A1:2010+A12:2011+A2:2013

The Technical Construction File is maintained at: Magnetek, Inc.
N49 W13650 Campbell Drive
Menomonee Falls, WI 53051 USA

The European contact for technical documentation is: Brian Preston
Magnetek
Unit 3, Bedford Business Centre
Mile Road
Bedford
MK42 9TW
United Kingdom

Per Annex II.B of the Machinery Directive (2006/42/EC):

The machinery, product, assembly or sub-assembly covered by this Declaration of Conformity must not be put into service until the machinery into which it is to be incorporated has been declared in conformity with the provisions of the applicable Directive(s). This statement is only necessary where the product is to be incorporated into a machine or system (e.g. a safety component).

Signature of Authorized Person:

Travis Tedesco
Engineering Development Manager
Columbus McKinnon Corporation
Bridgeville, PA USA

Date of Issuance: 31 January 2019

Peter Stipan
Director of Development
Columbus McKinnon Corporation
Menomonee Falls, WI USA